




M-Range Industrial Progressing Cavity Pumps

Installation and Operating Instructions



Quality • Availability • Service • Innovation • Value



Contents

1	SAFETY.....	2
2	GENERAL INFORMATION	2
3	INSTALLATION RECOMMENDATIONS	3
	3.1 IMPORTANT	3
4	DUTY CONDITIONS	4
5	PUMP DIMENSIONS.....	5
6	PUMPS SUPPLIED FOR FOOD APPLICATIONS.....	7
7	MOTOR WIRING ARRANGEMENT	7
8	STARTING	8
9	GUARDS	9
10	ROTATION	9
11	DRAWING REFERENCES NUMBERS.....	10
12	EXPLODED VIEW	11
13	DISMANTLING	12
14	RE-ASSEMBLY OF PUMP	13
15	ROUTINE MAINTENANCE	17
	15.1 GLAND PACKING	17
	15.2 COUPLING RODS AND UNIVERSAL JOINTS	17
	15.3 BEARINGS	18
16	MECHANICAL SEALS.....	20
17	PARTS VIEW: 22M, 24M, 31M, 33M.....	21
18	PARTS VIEW: 41M, 42M, 51M, 52M, 51MCR, 52MCR.....	22
19	PARTS VIEW: 61M, 62M, 62MB, 61MB	23
20	PARTS VIEW: 71M, 72M, 81M, 82M, 81MCR, 91M	24
21	PARTS VIEW: 92M, 101M, 111M.....	25
22	INSTALLATION DATA	26
23	TROUBLE SHOOTING	27
24	WARRANTY	28
25	NOTES	30



1. SAFETY

Before installing and using the PC pump, carefully read the instructions provided below. This manual contains fundamental instructions that must be followed during installation, operation and maintenance. This manual must be consulted by all qualified personnel who will follow the pumps operation and installation. In addition, this manual must always be available at the location where the pump is used.

Failure to respect the safety rules may cause physical and material damage, failure of the installation or the pump's principal functions; compromised maintenance operations; mechanical or electrical damage; injury to people as well as environmental pollution. Failure to observe safety rules can void the warranty.



This is the safety alert symbol, take special note of literature in this manual highlighted with this symbol. This symbol warns about hazards that may cause serious personal injury, death or property damage if ignored.

2. GENERAL INFORMATION

This manual covers operation and important recommendations for the correct operation of the pump. It is necessary to respect these recommendations in order to maximize the pumps reliability, longevity, as well as to avoid the risk of accident resulting from improper use. The pump must never be used outside the limitations described in the technical specifications. It is necessary to respect the instructions regarding product nature; density; viscosity; temperature; flow rate; pressure; speed; direction of rotation; power of motor as well as all other instructions contained in this manual or in the documentation attached to the contract.

The manufacturer declines all responsibility in the case of accident or damage caused by negligence, Improper use of the pump or the failure to observe the instructions provided in this manual or use under conditions other than those stated in the name plate data.

3. INSTALLATION RECOMMENDATIONS

At the pumping system design stage, consideration must be given for the provision of dedicated gauges, filling or flushing connections, non-return, isolating or pressure relief valves. Due to the nature of a positive displacement pump, it is recommended a pressure relief valve is installed on the outlet side of the pump to prevent any danger and or damage in the event the flow out of the pump becomes blocked.

3.1 IMPORTANT

- For ease of maintenance, the correct dismantling space must be provided (refer to the pump dimension sheet).
- All bolts and nuts securing flanges and base mounting fixtures must be checked for tightness before operation.
- All pipework should be independently supported.
- To eliminate vibration, the pump must be correctly aligned with the drive unit, all guards must be securely fixed in position, and mounted on a suitable baseplate.
- When commissioning the plant, all joints in the system must be thoroughly checked for leaks.
- Suction pipework must be clean to prevent trap material from damaging the pump. As an added precaution a temporary strainer may be fitted.




NEVER RUN THE PUMP WITH A CLOSED INLET OR OUTLET VALVE.

4. DUTY CONDITIONS


Pumps should be installed only in applications for which they were approved by Franklin Electric, having taken into account material compatibility, flow rates, temperature; solids handling; pressure; rotational speed and the environment. The performance capabilities of the Mono industrial pump range is shown on the chart below (based on water at 20°C).

Typical Performance Guide



Should any changes in the duty conditions be envisaged following pump selection / installation, Franklin Electric's recommendations should be sought in the interest of efficiency, safety and suitability.

5. PUMP DIMENSIONS



Pump Model	A	Dismantle Clearance	B	C	D	E	F	G	H	J	K
C22M	571	315	301	270	19	6	21,5	40	80	160	100
C24M	766	282	377	389	28	8	31	50	90	200	120
C31M	531	275	301	230	19	6	21,5	40	80	160	100
C33M	822	282	377	445	28	8	31	50	90	200	120
C41M	627	300	377	250	28	8	31	50	90	200	120
C42M	757	300	377	380	28	8	31	50	90	200	120
C51M	672	282	377	295	28	8	31	50	90	200	120
C52M	847	282	377	470	28	8	31	50	90	200	120
C51MCR	798	430	455	343	38	10	41	60	110	230	135
C52MCR	958	430	455	503	38	10	41	60	110	230	135
C61M	825	430	455	370	38	10	41	60	110	230	135
C62M	1040	430	664	585	38	10	41	60	110	230	135
C61MB	717	282	377	340	28	8	31	50	90	200	120
C62MB	1090	385	455	635	38	10	41	60	110	230	135
C61MCR	870	450	455	415	38	10	41	60	110	230	135
C71M	1041	510	604	437	48	14	51,5	80	160	320	175
C72M	1321	510	603	718	48	14	51,5	80	160	320	175
C81M	1041	510	604	437	48	14	51,5	80	160	320	175
C82M	1536	700	644	892	48	14	51,5	80	160	320	215
C81MCR	1338	700	644	694	48	14	51,5	80	160	320	215
C91M	1416	700	644	772	48	14	51,5	80	160	320	215
C92M	1866	1600	644	1222	48	14	51,5	80	160	320	215
C101M	1481	800	644	837	48	14	51,5	80	160	320	215
C111M	1416	690	644	772	48	14	51,5	80	160	320	215

Pump Model	N	P	Q	R	S	T	U	V	FLANGE	Z	MASS (kg)
C22M	100	35	121	120	305	70	10	10	BS4504	N/A	20
C24M	125	45	145	165	426	90	10	12	BS4504	N/A	38
C31M	100	35	121	120	305	70	10	10	BS4504	N/A	18
C33M	125	45	145	165	482	90	10	12	BS4504	N/A	40
C41M	125	45	145	165	287	90	10	12	BS4504	N/A	34
C42M	125	45	145	165	417	90	10	12	BS4504	N/A	40
C51M	125	45	145	165	332	90	10	12	BS4504	N/A	36
C52M	125	45	145	165	507	90	10	12	BS4504	N/A	44
C51MCR	140	50	169	200	389	105	13	14	BS4504	N/A	53
C52MCR	140	50	169	200	549	105	13	14	BS4504	N/A	58
C61M	140	50	169	200	416	105	13	14	BS4504	N/A	58
C62M	140	50	169	200	631	105	13	14	BS4504	N/A	71
C61MB	125	45	145	200	377	90	10	12	BS4504	N/A	38
C62MB	140	50	169	200	681	105	13	14	BS4504	N/A	74
C61MCR	140	50	169	200	461	105	13	14	BS4504	N/A	57
C71M	200	70	221	210	560	150	20	16	BS4504	N/A	113
C72M	200	70	220	210	841	150	20	16	BS4504	N/A	141
C81M	200	70	221	210	560	150	20	16	BS4504	N/A	112
C82M	200	70	261	210	1015	150	20	16	BS4504	378	191
C81MCR	200	70	261	210	817	150	20	16	BS4504	378	169
C91M	200	70	261	210	895	150	20	16	BS4504	378	173
C92M	200	70	261	210	1345	150	20	16	BS4504	465	231
C101M	200	70	261	210	960	150	20	16	BS4504	465	176
C111M	200	70	261	210	895	150	20	16	BS4504	378	192



6. PUMPS SUPPLIED FOR FOOD APPLICATIONS

For pumps intended for food/hygienic applications, it is imperative that the correct material selection is applied. It is important that a clean in place treatment is executed on the pump at the following times (in addition to the standard CIP plan during normal pump operation):

1. When the pump is first commissioned for use.
2. When any spare components are fitted/replaced.



Hypalon stators should not be used in applications where product is destined for human consumption. Hygienic applications do require stainless steel pump components. Contact Franklin Electric for more information regarding use of food grade grease for specialized applications.

7. MOTOR WIRING ARRANGEMENT

This PD pump requires a high starting torque to overcome the rotor stator friction fit. To achieve this the motor must be started direct on line (DOL) to realize maximum starting torque. Star-delta starting is not recommended. Higher power motors, requiring starting currents in excess of supply capability need to be powered using variable frequency drives (VFD).



Star-Delta and reduced voltage (soft starters) are not recommended for PD pumps.

Consideration must be given to applications using electronic variable frequency drives, these systems:

1. Must make use of VFDs with full torque rating at start-up (as opposed to a square law drive) or
2. Use a larger motor than required according to selection (to offer greater starting torque at standstill) when operating direct online.

For applications where the motor will not be operating at full frequency, derating the motor must be accounted for to cope with torque demands within the required RPM range.

Test the motor rotation direction to ensure it is correct as required for pump operation.

Failure to follow this guidance may result in the pump not starting, not being capable of producing the required duties or lead to motor failure.

8. STARTING

Pumps must be filled with liquid / product before startup. This initial filling is not for priming purposes but to provide the necessary lubrication for the stator until the pump primes itself.


When the pump is stopped, sufficient liquid is normally trapped within rotor stator set to provide lubrication on following startup. If the pump has been standing for a long period of time, or has just been moved to a new location, or has been dismantled for examination it must be filled with liquid and be given a few turns by hand before starting. The pump is normally somewhat stiff (dependant on the model) to turn by hand on account of the close fit between the rotor and the rubber stator. If on start up, the pump does not operate correctly, the plant must be shut down immediately and the cause of the malfunction established before operations are recommenced.



Never run the pump in a dry condition, even for a few revolutions or the stator will be damaged.

Startup check list:

1. With the motor isolated from the pump, ensure that its rotation is the correct direction.
2. Are there any obstructions in the pipework or pump?
3. Are the pump connections and pipework points tight and leak free?
4. Have the inlet and outlet protective plugs been removed?
5. Is there lubrication in the drive unit / gearbox?
6. Does the product seal require a flushing arrangement?
7. Is the gland follower loose (If packed gland version)?
8. Is motor voltage correct?
9. For V-belt arrangement, is belt tension correct? Rule of thumb is 16mm deflection ("d") per 1m belt length.



10. For coupling arrangement, are shafts aligned?
11. Are the pipework valves open?
12. Are all safety guards in place?
13. Is the pump filled with 'product' to provide lubrication between the rotor and stator on start up?
14. Start then stop the pump; is the pump rotating in the correct direction?



The pump speed / pressure settings must remain below the pumps maximum limitations. Consult Franklin Electric if you are unsure.

If the pump has never been run, it may be necessary to crank the pump through one revolution manually (with water/product present in the gland). This can be achieved by using an adjustable wrench fitted at the drive shaft.

9. GUARDS



In accordance with the Health & Safety Act, all guards must be secured after installation, maintenance or any adjustments have been made to the pump.

10. ROTATION

The M-Range of Industrial pumps is suitable for rotation in either direction, i.e. flow direction out either of the pump flanges. The bearing housing direction plate indicates the resultant flow path dependent on mainshaft rotation direction. Pump flow curves also indicate flow direction.

NOTE: It is recommended product flow is directed out the “end cover” (opposite drive end) side of the pump in applications where:

- Pressure above 10 bar is required (dependant on pump capabilities)
- No suction lift is required. For Suction lift applications, delivery must be on gland.

11. DRAWING REFERENCE NUMBERS

ITEM NO.	DESCRIPTION	QTY PER PUMP
1	End cover	1
2	Plug	2
4	Rotor	1
5	Moulded Stator	1
6	Extension Piece	1
8	Gland section / Porting Chamber	1
9	Packing ring	1 set
10	Gland follower	1
11	Thrower / Flinger	1
12	Bearing housing	1
13	Bearing locknut	1
14	Bearing lock washer	1
16	Bearing distance piece	1
17	Bearing taper roller	2
18	Shaft bearing collar	1
19	Bearing cover	1
20	Pin cap guard	1
21	Main shaft	1
22	Key	1
23	Washer pin cap	4
24	Pin cap	4
25	Pin coupling rod	2
26	Coupling rod bush	2
27	Seal ring coupling rod	2
28	Coupling rod	1
34	Lip seal	1
34A	Lip seal - Drive end	1
35	Gland stud	2
37	Seal housing / Loose gland	1
39	Tie rod	4
44	Sealing Boot	1
46	Pin cap guard Bolt	2
50	Hex nut gland stud	2
51	Spring washer	16
54	Hex bolt bearing cover	4
55	Hex bolt gland section	4
85	Subassembly (Bearing housing incl internal comp.)	1
88	Gasket - Loose gland	1
88A	Gasket (Extension piece)	1

12. EXPLODED VIEW




Figure 1 - Exploded view



13. DISMANTLING



Before any maintenance work is carried out on the pump, ensure that the pump is isolated from the electrical supply and that the pump's main isolating valves on the inlet and outlet are closed. Ensure that the system is de-pressurised.



Where hazardous fluids are pumped, the pump must be flushed and drained before the dismantling. Personnel dismantling the pump must wear protective clothing throughout the dismantling procedure.

If the pump has been out of operation for more than one hour, it will assist dismantling if the rotor is given a slight turn, thereby breaking the rotor/stator seal. Where a pump has been out of operation for a longer period of time, dismantling can be facilitated by lubricating the rotor/stator assembly with water through the filling plug holes, and rotating the rotor.


To dismantle the pump, follow the below sequence (reference to Figure 1 : Exploded view):

1. Remove bolts holding end cover (01) to baseplate/foundation.
2. Loosen tie rod nuts and tie rods (39)
3. Remove end cover (01).
4. Remove stator (05). It may be necessary to rotate mainshaft (21) with suitable spanner while gripping stator (05) to assist with this operation.
5. Remove pin cap guard (20) at drive shaft end.
6. Remove drive end pin cap (24) and lock washer (23) and withdraw coupling pin (25) with pliers.
7. The rotor (04) with attached coupling rod (28) can now be removed by pulling away from the mainshaft (21).
8. Loosen 4 hex bolts (55) holding porting chamber (08) to bearing housing (12). Loosen gland hex nuts (50).
9. Porting chamber (08) and loose gland (37) can now be removed.
10. Loosen hex bolts (54) and remove bearing cover (19) at drive end.
11. Withdraw the mainshaft (21). Bearings (17) and lipseal (34) will pull-out with mainshaft (21).
12. Strip bearing lock nut (13) and bearing lockwasher (14) to remove bearings.


14. RE-ASSEMBLY OF PUMP

Refer to Figure 1 : Exploded view :


1. Assemble bearings (17) on mainshaft (21) with bearing spacer (16) in between, and bearing lock washer (14) on open end.
2. Fasten bearings (17) on mainshaft (21) with bearing lock nut (13). See 15.3 BEARINGS for bearing settings. Ensure bearings (17) are greased liberally.
3. Insert the mainshaft assembly (21) in bearing housing (12).
4. Bolt bearing cover (19) to bearing housing (12) with hex bolts (54).
5. Install lip seal (34) and drive end lip seal (34A). Lip seal opening must face inwards.
6. Install thrower / flinger (11) on mainshaft.
7. Place gland follower (10), and then loose gland (37) onto mainshaft (21) from gland end.



8. Place gasket (88) in gland section (08) recess, and bolt gland section to bearing housing (12). Flange can be positioned in any orientation.
9. Install gland packing (09) into loose gland section (37). Packing must be inserted with each consecutive packing rotated 180°. Gland follower (10) can be tightened in place loosely. Gland follower (10) must be tightened once pump is running, it must be tightened such that the gland continues to drip (a drip a second). See 15.1 GLAND PACKING.
10. Fit seal rings (27) onto coupling rod (28) by greasing rod joint ends and pulling them over at each end by hand.
11. Fit one pin cap (24) in rotor (04) end with lock washer (23). Lock lockwasher (23) by folding wide tab up against pin cap (24) and folding the narrow tab into rotor head groove - see illustration below. Always replace a damaged or missing lock washer (23) and or seal ring (27), this will prevent grease leakage from the joint and increase pump service intervals.




12. Fill rotor joint cavity with grease, insert coupling rod (28) head into rotor (04) cavity.
13. Insert coupling rod pin (25) and fit second lock washer (23) and pin cap (24). Repeat locking of lock washer (23).



14. Fit one pin cap (24) and lock washer (23) to mainshaft (21) joint interface.
15. Pack grease into the joint interface on the mainshaft (21). Smear the open end of the coupling rod liberally with grease and insert into the hollow mainshaft (21). Fit pin (25), remaining lock washer (23) and pin cap (24).

16. Bend locking tabs on the pin cap lock washers as per step 9.
17. Fit stator (05) ensuring it seals up against porting chamber (08). Rotate stator (05) while rotor (04) is held stationary to assist with fitment. One can use water, silicone grease or a rubber compatible liquid as a lubricant on rotor to assist with fitment of stator.
18. Refit end cover (01) and tie rods (39). Tie rods must be tightened sequentially to ensure an even clamp between the stator and adjacent castings. Tighten rods according to sequence below repeating the cycle 3 times until the correct torque rating is achieved. See torque chart below.



MODEL	TIE ROD TORQUE (NM)
22M	12
24M	12
31M	12
33M	12
41M	12
42M	12
51M	12
52M	12
51MCR	12
52MCR	12
61M	12
62M	12
61MB	12
62MB	12
61MCR	12
71M	18
72M	18
81M	25
82M	25
81MCR	40
91M	40
92M	40
101M	65
111M	65

15. ROUTINE MAINTENANCE

To ensure optimum pump life the following components should be routinely checked:

1. **Gland Packing** (refer to 15.1 GLAND PACKING).
2. **Universal Joints** - Joints should be greased every 500 - 1,000 running hours but this period could be more or less depending on duty conditions. Castrol Spheerol LMM or equivalent grease to be used for this purpose.
3. **Pins** - Pin wear can be detected by rocking the pump driving pulley or coupling to determine the amount of free play. If the angular deflection is excessive (greater than 5°) the universal joints should be replaced (refer to 13. DISMANTLING).
4. **Bearings** - Bearings should be cleaned and regreased every 5,000 hours.

15.1 GLAND PACKING

The gland packing supplied as a standard in these pumps is manufactured from a non-asbestos material (PTFE or cotton graphite). The gland will require adjustment during the initial running-in period. Under normal working conditions a slight drip from the gland is essential and assists in lubricating the packing.

It is usual to replace gland packing when re-assembling a pump. Clean the box and shaft thoroughly and examine mainshaft (21) for wear and scoring. Replace shaft if its wear is excessive. Install one ring at a time. Make sure it is clean, and has not picked up any dirt in handling. Joins of successive rings should be staggered and kept at least 90 degrees apart.

After the last ring is installed, take up bolts finger tight. Do not jam the packing into place by excessive gland loading. Start pump, allow packing to leak freely. Excessive leakage during the first hour of operation will result in a better packing operation over a longer period of time. Take up gradually on the gland as the packing seats, until leakage is reduced to a tolerable level, preferably 8-10 drops per minute per inch of shaft diameter. Stopping leakage entirely at this point will cause the packing to burn up. A gland which is too tight can be detected by insufficient leakage and excessive heat in gland area and should be slackened off.

15.2 COUPLING RODS AND UNIVERSAL JOINTS

The universal joints of the coupling rod are designed such that any wear occurring at these points bears on small, inexpensive and easily replaceable bushes.

The universal joints are protected by rubber seal rings to retain the grease inside the joint.

The following models utilize bushes: 61M, 62M, 61MB, 62MB, 61MCR, 71M, 72M, 81M, 82M, 81MCR, 91M, 92M, 101M, 111M. The renewable bushes (26) in the coupling rod can be pressed out and replacements inserted. When replacing the bushes it is imperative they are aligned such that the hole elongation lies directed along the length of the coupling rod as per image below. Failure to do this will result in component damage.



15.3 BEARINGS

Bearings are removed from the shaft by following steps in 13. DISMANTLING.

RECOMMENDED PROCEDURE FOR SETTING THE CORRECT RUNNING CLEARANCES IN THE BEARINGS.

1. After assembling the bearings (17) and bearing spacer (16) onto the shaft, place the assembly in a vertical position and align the bearing cups and spacer to run concentric with the shaft axis (using straight edge or steel ruler).
2. Rotate the bearing cups and spacer by hand and tighten the locknut until resistance is felt in the bearing assembly. At this point all free running clearance is eliminated. (This operation should be carried out with bearings 'dry', i.e. no grease, only a protective coating).
3. The locknut should now be loosened to give correct running clearance (see table below).
4. The tab of the lock washer should now be bent into a corresponding slot on the locknut.
5. Bearing Lubrication - The taper roller bearings should be packed with Castrol Spheroil EP2 grease or equivalent and the housing 1/3 filled.

Bearings should be cleaned and re-packed with grease every 5,000 hours.

Model	Bearing	Required Axial Clearance	Anti clockwise clearance locknut rotation for correct clearance
22M	31307	0.05mm-0.07mm	15°
24M	31307	0.05mm-0.07mm	15°
31M	31307	0.05mm-0.07mm	15°
33M	31307	0.05mm-0.07mm	15°
41M	31308	0.05mm-0.07mm	15°
42M	31308	0.05mm-0.07mm	15°
51M	31308	0.05mm-0.07mm	15°
52M	31308	0.05mm-0.07mm	15°
51MCR	31308	0.05mm-0.07mm	15°
52MCR	31308	0.05mm-0.07mm	15°
61M	31310	0.06mm-0.08mm	15°
62M	31310	0.06mm-0.08mm	15°
61MB	31310	0.06mm-0.08mm	15°
62MB	31310	0.06mm-0.08mm	15°
61MCR	31310	0.06mm-0.08mm	15°
71M	30314	0.1mm-0.12mm	20°
72M	30314	0.1mm-0.12mm	20°
81M	30314	0.1mm-0.12mm	20°
82M	32217	0.2mm-0.25mm	40°
81MCR	32217	0.2mm-0.25mm	40°
91M	32217	0.2mm-0.25mm	40°
92M	32217	0.2mm-0.25mm	40°
101M	32217	0.2mm-0.25mm	40°
111M	32217	0.2mm-0.25mm	40°

16. MECHANICAL SEALS

Mechanical seals are used in applications where zero leakage from the pump gland section is required. Mechanical seals can be ordered with a new pump assembly or alternatively be fitted at a later stage replacing the existing gland packing. Franklin Electric should be contacted to assist with the selection of a suitable mechanical seal. Part numbers of standard options are listed below.

Model	Mechanical seal size	Component Mechanical seal - Silicon Carbide/Silicon Carbide/Viton Max-12 Bar	Cartridge Mechanical seal - Silicon Carbide/Silicon Carbide/Viton Max-12 Bar	Cartridge Mechanical seal - Silicon Carbide/Silicon Carbide/Viton Max-20 Bar	Cartridge Mechanical seal - Tungsten Carbide/Tungsten Carbide/Viton Max-20 Bar
22M,31M,32M, 2/1, 2/2	30mm	830009174	830009181	830011196	830011203
24M, 33M, 41M, 42M, 51M, 52M, 61MB, 4/1, 4/2	35mm	830009 175	830009 182	830011 197	830011 204
61M, 62M, 62MB, 51 MCR, 52MCR, 61MCR, 15/2	45mm	830009 176	830009 183	830011 198	830011 205
71M,72M,81M, 22/1, 22/2, 15/4	65mm	830009 177	830009 184	830011 199	830011 206
80/1, 80/2, 120/1, 120/1, 50/4	75mm	830009 178	830009 185	830011 200	830011 207
82M,91M,92M, 81MCR, 35/2, 101M, 111M, 50/2, 22/4, 35/4	80mm	830009 179	830009 186	830011 201	830011 208
150/1, 150/2, 225/1	85mm	830009 180	830009 188	830011 202	830011 209



Franklin Electric must be consulted for mechanical seal selection assistance in instances where the seal will be exposed to hazardous products / liquids.

17. PARTS VIEW: 22M, 24M, 31M, 33M




Figure 1

18. PARTS VIEW: 41M, 42M, 51M, 52M, 51MCR, 52MCR




Figure 2

19. PARTS VIEW: 61M, 62M, 62MB, 61MB




Figure 3

20. PARTS VIEW: 71M, 72M, 81M, 82M, 81MCR, 91M




Figure 4

21. PARTS VIEW: 92M, 101M, 111M




Figure 5

22. INSTALLATION DATA

Complete the installation data documentation for warranty purposes and for future referencing.

PUMP INSTALLATION DATA SHEET
Customer :
Date of installation
Pump size
Product pumped
Temperature. °C
Pump speed. rpm
Driver speed. rpm
Pumped capacity. m³/hr
Pressure at pump. kPa
Drive. motor/engine/tractor
Drive power rating
Relieve valve fitted. Yes/no
Method of starting. DOL/Star Delta
Altitude. m
Suction conditions
pH
Viscosity (cP)
Solids content. %
Solids detail
Specific Gravity
Materials of construction
Mech. seal or packed gland
Pump serial no
Stator serial no
Length and dia of suct. line. m / mm
Length and dia of del. line. m / mm
Suction or delivery on gland

24. WARRANTY

This document contains Franklin Electric Co., Inc. and all of its subsidiaries (collectively, "Franklin Electric") standard limited warranty, general sales policies and controlling terms and conditions for Submersible Pump (the "Goods"). This document shall not be altered or amended except as provided by Franklin Electric.

Limited Warranty

Franklin Electric warrants that for a period of one (1) year from the date of delivery, the goods purchased will:

- (a) Be free from defects in workmanship and material at the time of shipment;
- (b) Perform consistently with samples previously supplied; and
- (c) Conform to the specifications published or agreed to in writing between the customer and Franklin Electric.

This limited warranty is in lieu of all other warranties, written or oral, statutory, express, or implied, including any warranty of merchantability or fitness for a particular purpose. Customer's sole and exclusive remedy for Franklin Electric's breach of its obligations hereunder, including breach of any express or implied warranty or in a written instrument made of this limited warranty, shall be for the purchase price paid to Franklin Electric for the non-conforming or defective product or for the repair or replacement of non-conforming or defective product, at Franklin Electric's election.

Any Franklin Electric product which Franklin Electric determines to be defective within the warranty period shall be, at Franklin Electric's sole option, repaired or replaced, provided that Franklin Electric's obligation to repair or replace shall be subject to the following conditions:

- (a) Any allegedly defective goods or parts shall have been returned to Franklin Electric at the customer's expense;
- (b) The customer shall establish in writing to the reasonable satisfaction of Franklin Electric that the goods have been properly used and applied for normal purposes;
- (c) No person, whether authorised by the customer or not, shall have tampered with the goods or parts or shall have attempted to rectify the alleged defect in the goods or parts in any way before the inspection thereof by representatives of Franklin Electric; and
- (d) Notwithstanding anything to the contrary contained herein, whether or not Franklin Electric has repaired or replaced alleged defective goods, Franklin Electric shall be entitled at any time to refund the purchase price of any allegedly defective goods to the customer and such refund shall be in full and final settlement of such customer's claim in respect of the allegedly defective goods.

Without limiting the generality of the exclusions of this limited warranty, Franklin Electric does not warrant the adequacy of any specifications provided directly or indirectly by a customer or that Franklin Electric's products will perform in accordance with such specifications.

This limited warranty does not apply to:

- (a) Any goods that have been subject to misuse (including use in a manner inconsistent with the design of the product), abuse, neglect, accident or improper installation or maintenance; and
- (b) Any goods that have been altered or repaired by any person or entity other than Franklin Electric or its authorised representatives;
- (c) Any goods not manufactured by Franklin Electric unless Franklin Electric is entitled to the benefit of the same or similar undertaking, mutatis mutandis from the supplier or manufacturer thereof. In such case, Franklin Electric's liability to the customer for such goods shall be limited to Franklin Electric's benefit from the supplier or manufacturer thereof.

Stated performance figures are based on Franklin Electric's testing experience. Franklin Electric shall not be liable for any loss or damaged incurred or sustained by the customer as a result of the customer's reliance on such figures unless Franklin Electric shall in writing, have:

- (a) Guaranteed such performance figures within specified tolerances; and
- (b) Agreed to pay a penalty or liquidated damages in the event of such performance figures not being achieved, in which event Franklin Electric's liability shall be strictly limited to the amount of such agreed upon penalty or damages.

Notwithstanding anything to the contrary, Franklin Electric shall not be liable, under any circumstances, for:

- (a) Any loss of trade or profit occurring to the customer in the event of the delivery of goods being frustrated or delayed by acts of God or force majeure such as, but not limited to, strikes, riots, lockouts, trade disputes, fire, war, mobilisation, military conscription, confiscation, uprising, trade embargoes, shortage of raw materials, or by any other cause beyond Franklin Electric's control, and
- (b) Loss of profit or any special, incidental or consequential damages whatsoever whether arising from breach of contract, delict, negligence, or from any other cause, even if Franklin Electric shall have been advised of the possibility of such potential loss or damage.



Franklin Electric

HEAD OFFICE AND FACTORY

PO Box 8136, Edenglen 1613, South Africa
13 Engwena Road, Sebenza, Edenvale 1610
Tel: +27 11 723 6500 Fax: +27 11 609 2417
E-mail: info@franklin-electric.co.za
Website: www.franklin-electric.com

EXPORTS

PO Box 8136, Edenglen 1613, South Africa
13 Engwena Road, Sebenza, Edenvale 1610
Tel: +27 11 723 6500 Fax: +27 11 452 2699
E-mail: info@franklin-electric.co.za
Website: www.franklin-electric.com

BRANCHES

DURBAN

Tel: +27 31 700 4160 Fax: +27 31 700 4103

BLOEMFONTEIN

Tel: +27 51 434 1565 Fax: +27 51 435 3819

CAPE TOWN

Tel: +27 21 949 5458 / 5424 / 5448
Fax: +27 21 949 5459

ZAMBIA

PO Box 71253, Ndola, Zambia
Tel: +260 21 265 0617 / 9
Fax: +260 21 265 0852
E-mail: info@fele.com

DEPOTS

POLOKWANE

Tel: +27 15 298 8748

PORT ELIZABETH

Tel: +27 41 487 2866 / 2985 / 3058 / 3059
Fax: +27 41 487 2980

BOTSWANA

Private Bag BR 225, Broadhurst, Gaborone
Plot 42 Gaborone International Commerce Park
Tel: +267 397 4926 Fax: +267 397 4927
E-mail: info@fele.co.bw
Website: www.franklin-electric.com

Contact us for your nearest reseller